
Cineroid **EVF**

Electronic View Finder

User Manual



Cineroid



I Thank you for purchasing the Cineroid EVF.

The Cineroid EVF (hereafter referred to as "EVF") is a view finder that can be mounted on any video camera with a HDMI output signal. Please thoroughly read the user manual for best operation and understanding of all of the functions of the EVF.

Test Before Operating

It is recommended to test the EVF before operating. Check if the EVF can be turned on once powered, and check if the information/menu is being properly displayed on the LCD.

Copyrights and Prohibitions

The use of images of people, property, and places can without permission can be prohibited by law. Please refer to your region's laws regarding copyrights.

- O Canon and EOS are registered trademarks of Canon.
- O Nikon is a registered trademark of Nikon.
- O Sony is a registered trademark of Sony.



Safety Precautions

Please observe the following safety precautions as they are meant for the safe and proper use of the product to reduce the risk of accidents. Upon reading the user manual, keep it in a safe and available place.



Do not face the eyecup directly into the sun as it may damage the LCD.

- O Do not use any batteries, power cord, or accessories that are not specified in this document
- When using a power cord, be sure to plug it in completely. Do not handle power plugs when your hands are wet. When unplugging the power cord, grasp the plug body or adapter instead of the cord.
- O Power cords that are scratched, heavily bent or twisted can potentially be hazardous and a source of electric shock and/or fire
- © Do not insert foreign objects into the product's electric or cable components.
- O Do not place the power cord near sources of heat as this may melt or cause damage to the cord potentially causing fire or electric shock.
- O Do not disassemble or modify the product. This may damage the product and cause danger due to a malfunction.
- Please keep the product out of reach of young children. Injuries may occur due to damage to the product.
- When using the product in an airplane or hospital setting, it is recommended to acquire authorization first as signals or electro-magnetic waves from the product may cause other equipment to malfunction.
- © Do not store the product in a dusty or humid environment as damage may occur.
- When the product is mounted on a camera, do not lift or move the camera by grabbing the product. This may cause damage to the product or the camera mount,
- O Do not clean the product with paint thinner, benzene, or other volatile solvents. This may cause damage to the product and become a fire hazard.
- This product is not waterproof. If the product is dropped in water, contact the service center immediately.



I Table of Contents

Safety Precautions ·····	03
Table of Contents ····	04
Configuration	06
Parts	07
Before Using the EVF	
Detachable Optical Viewfinder	08
Installing the Battery	
Connecting External Power	
Powering On/Off ·····	09
Adjusting the Diopter · · · · · · · · · · · · · · · · · · ·	10
Connecting a HDMI Cable	10
Connecting a Composite Cable	11
Connection a Monitor	11
Basic Features	
Operating the Menu ·····	12
Input Selection	13
Adjusting Color ·····	
Adjusting the Screen · · · · · · · · · · · · · · · · · ·	
Adjusting the Volume	14




Shooting Features	
Peaking ·····	15
Saturation (Exposure)	16
Underscan ·····	16
Pixel to Pixel ·····	17
Monochrome B/W	17
4:3 Guide bar ·····	18
Screen Flip ·····	18
Setting User Controls	
Custom Button Functions	
Custom Display Setting	
OSD Color Setting	20
Factory reset ·····	20
Product Specifications	21
Optional Products	22




I Components

Please ensure all parts are present after opening the box.





Parts






Detachable Optical Loupe


- 1. The optical loupe attached to the EVF body can be flipped open 180 degrees or detached completely.
- To open the optical loupe, firmly grasp the loupe and flip upwards. When it is fully open. the loupe will stay fixed on top of the body.
- 3. To completely detach the loupe from the body, simply slide the small latch to the left and lift up the loupe. To replace the loupe, slide the small latch to the left and place the loupe back into place.






Installing the Battery

- 1. The Cineroid EVF can be used with small, medium or large sized batteries. The battery cover can only be used with the small sized batteries.
- 2. Remove the battery cover.
- 3. Push the battery in towards the direction of the arrow making sure the battery is properly aligned in place.
- 4. The battery or the connectors may be damaged if not aligned properly.
- 5. The Canon LP-E6 battery can only be used in conjunction with the proper adapter.









Connecting External Power

- 1. External power is supplied through the use of the PAO1 adapter.
- 2. Proper voltage for external power is 6–17V.
- 3. To install the PA01 adapter, first remove the battery from the body.
- 4. Connect the external power cable to the PAO1 adapter, as illustrated in the picture below.
- 5. Install the PA01 adapter to the body using the same method as installing the battery.
- 6. You can use the Canon LP-E6 battery with the PA01 adapter installed.



Powering On/Off


- 1. Install the battery or connect external power.
- 2. Turn the power switch to the ON position.
- 3. A red light will indicate that the power and LCD is turned ON.
- 4. If you have an external input, you will see the image displayed from that signal. If there is no external input, you will see the default screen.
- 5. Turn the power switch to the OFF position to turn off.





Adjusting the Diopter

- 1. When viewing through the optical loupe, the user can adjust the diopter accordingly. Turn on the EVF and verify the LCD image output,
- Rotating the dial to the right will bring the eye cup towards you and rotating it to the left will move the eye cup away from you.
- 3. Rotate the dial in either direction until the image becomes clear.



Connecting a HDMI Cable

- 1. Make sure the EVF input selection is set to HDMI, Please refer to 'Input Selection' on page 13.
- First connect the mini-HDMI cable to a camera, and then connect the other end into the HDMI IN connection on the EVF.
- Check whether the image on the LCD is correctly displaying the image on the camera. If the image on the LCD is not displaying correctly, check the cable connections and/or the camera to ensure all settings are correct,






Connecting a Composite Cable

- 1. Make sure the EVF input selection is set to Composite. Please refer to 'Input Selection' on page 13.
- 2, You can purchase a composite cable from Cineroid or use your own cable if it is similar to the illustration below.
- 3. Insert the 3.5mm dia 4-pole plug into the rear of the EVF marked A/V in.
- Check the image.



Connecting an External Monitor (EVF4L)

- 1. The EVF4L model provides a HDMI loop-through function. The image on the LCD can be directly looped to an external monitor via a separate mini-HDMI cable.
- 2. Connect the mini-HDMI input cable to the EVF HDMI in.
- Connect a separate mini-HDMI cable from the EVF HDMI out to an external monitor.
- 4. If there is no input signal into the EVF, then there will be no image to the external monitor.
- 5. The EVF4B model does not come with a loop-through function.







Basic Features

Operating the Menu

- 1. Access the setting and features by pressing the menu button on the left side of the EVF.
- Press the M button to select the main menu. When not in the menu, you can adjust the speaker volume by pressing the up and down arrow keys.



- Once the main menu is selected, press the up and down arrow keys to navigate through the menu. The cursor is highlighted in red.
- Move the cursor to the feature you want to select/change and press the M button to access that feature
- 5. Press the up and down arrow keys to change the value of the feature.
- 6. Move the cursor to Exit and press the M button to return to the previous menu.
- 7. To exit the main menu, move the cursor to Exit and press the M button.



tip TIP: To exit out of the main menu immediately, press any of the buttons (PK, F1, F2, SA) on the right side of the EVF.



Basic Features

Input Selection

- You can choose between composite and HDMI for your external input selection.
- 2. The HDMI input can receive 480i, 480p, 576p, 720p and 1080i signals.
- 3. Press the M button for the main menu, Move the cursor to INPUT SELECT and press the M button. Choose either HDMI or Composite.
- 4. Highlight and select Exit to return to the main menu.





Adjusting Color

- 1. You can adjust the color of the LCD screen, Choose 0-50 for the color levels.
- Press the M button for the main menu.
- 3. Select COLOR ADJUST and choose between Red, Green or Blue to adjust your colors.
- 4. A preview window will appear on the lower right portion of the screen as you adjust your colors.






Basic Features


Adjusting the Screen

- 1. You can adjust the LCD brightness, contrast, and sharpness, Choose between 0-50 for the brightness and contrast and 0-10 for the sharpness,
- 2. Press the M button for the main menu.
- Select SCREEN ADJUST choose between BRIGHTNESS, CONTRAST, and SHARPEN to adjust your screen.
- A preview window will appear on the lower right portion of the screen as you adjust your screen.



Volume Control

- The EVF has a built—in speaker on the left side of the body and a headphone jack on the right side.
- You can adjust the master volume by pressing the up and down arrows on the left side of the EVF when not in the main menu screen. You can also adjust the master volume within the menu. Press the M button for the main menu. Select VOLUME and adjust with the arrow keys.
- The speaker and headphone volumes can be adjusted independently. To do so, you must adjust the volume within the menu.
- You can use the speaker and headphones simultaneously and you can also mute the volume within the menu.







Peaking

- 1. The EVF provides the peaking feature in both the Red and Sharpness mode, The Red mode displays in red and the Sharpness mode displays an outline in white.
- 2. To activate the peaking feature, simply press the PK button on the left side of the EVF body. The peaking will show in the mode that is currently selected.
- 3. To change the peaking mode, press the M button for the main menu. Select PEAKING from the menu and then select PEAKING MODE. Select R for Red or S for Sharpness. mode. You can also adjust the peaking threshold by selecting PEAKING THRESHOLD and adjusting accordingly. The threshold range is 1-5 with 5 being the highest,
- 4. The peaking feature works only with HDMI input, It does not work with Composite,







Peaking Red OFF

Peaking Red ON







Peaking Sharpness OFF



Peaking Sharpness ON

Otip Peaking Mode: R → Red

S → Sharpness



Saturation(Exposure)

- 1. You can use the saturation feature to determine proper exposure.
- 2. To activate the saturation feature, press the SA button on the left side of the EVF body. Under exposed areas are displayed in white and over exposed areas are displayed in the black diagonal lines.
- Proper exposure is displayed in the opposite diagonal lines.
- 4. Pressing the M button while the saturation feature is activated will allow you to change the over and under exposure saturation value, Press the up and down arrow buttons to change the values and use the M button to alternate between the over exposure and under exposure. You can also change the values from within the main menu.
- 5. Under exposure detection will be off if OFF under 0 is selected in unexposure threshold setting. Over exposure detection will be off it OFF over 100 is selected in over exposure threshold setting.









Saturation Value

Underscan

- 1. You can view every corner of the image on the LCD by activating the underscan feature. You can select the underscan feature from within the main menu or by custom setting the F1 or F2 button
- 2. When the underscan feature is activated, the entire image is slightly decreased in size from the original,









Underscan ON





Pixel to Pixel

- 1. Enabling pixel to pixel eliminates the need for you to zoom in/out of your native video.
- 2, If the native video is larger than the LCD resolution then that creates a zooming effect, Conversely, if the native video is smaller than the LCD resolution then that creates a scale-down effect.
- 3. The pixel to pixel feature only maps the center of the video image.
- 4. You can select either one-time mode or continuous mode pixel to pixel under Custom Setup of the menu.









Pixel to Pixel OFF

Pixel to Pixel ON

Monochrome (B/W)

- 1. You can view the image on the LCD in B/W by activating the monochrome feature.
- 2. To activate the monochrome feature, press the M button for the main menu, select MONOCHROME and turn the feature on. You can also assign this feature to one of the custom buttons, F1 or F2, in order to activate the feature immediately.





Monochrome (B/W) OFF



Monochrome (B/W) ON



4:3 Guide bar

- 1. The aspect ratio of the EVF screen is 16:9. Activating the guide bar will provide a 4:3 ratio by making both ends of the screen area a little darker.
- Once you active the guide bar from within the menu, the right side and left side of the screen area will become slightly darker. The unchanged area of the screen is the 4:3 aspect ratio.







4:3 Guide Bar OFF

4:3 Guide Bar ON

Screen Flip

- You can flip the video image on the LCD screen 180 degrees vertically or horizontally by activating the screen flip feature.
- To flip the image horizontally, from the main menu select SCREEN FLIP then turn MIRROR on.
- 3. To flip the image vertically, from the main menu select SCREEN FLIP then turn ROTATE on,





Mirror OFF / Rotate OFF







Mirror ON




Rotate ON



Setting User Controls

Custom Button Functions

- 1. The left side of the EVF body contains the buttons PK, F1, F2, SA, The factory default for these buttons are peaking (PK), monochrome (F1), underscan (F2), and saturation (SA),
- 2. Each button can be customized to a particular feature by selecting CUSTOM SETUP on the main menu
- 3. Press the M button for the main menu then select CUSTOM SETUP.
- 4. Select one of the buttons (PK, F1, F2, SA) you wish to customize. Select from one of the features listed to assign that feature to the selected button.
- 5. Exit out of the menu.







Setting User Controls

Custom Display Settings

- 1. You can select to view the current state of the battery usage, volume, etc., on the LCD,
- 2, Press the M button for the main menu and select STATUS DISPLAY to view the options.
- 3. Select ON or OFF for each item you want to view or not view on the LCD.
- 4. The pixel to pixel display only appears when the feature is activated.







Status Display Menu

Pixel to Pixel ON

Peaking ON

OSD (On Screen Display) Color Settings

- 1. You can select what color you want the menu and other items to be displayed on the LCD.
- 2 Press the M button for the main menu and select STATUS DISPLAY then OSD COLOR. Choose the color you want to use.
- 3 Confirm the new color in the LCD







OSD Color Yellow

OSD Color Green

Factory reset

- 1. Powering on the EVF while pressing down the PK button will reset the EVF to its original default settings.
- 2. Once the reset is complete, fully power off the EVF before powering on for further use.





Product Specifications

	Size	3,2inch TFT LCD	
	Resolution	800 x 480	
LCD	Color	16.7M	
	Viewing angle	H: 180 degrees, V: 180 degrees	
	Display area	69.6(H) x 41.76(V)mm	
Input	HDMI	(480i/480p/576p/720p/1080i)	
input	Composite	Video/Stereo Audio	
Video output	HDMI	(480i/480p/720p/1080i/1080p)	
Audio out	Phone Jack	3.5 ∮ Analog stereo	
Audio out	Internal speaker	Mono Output	
Power	Battery	Small, Medium, Large	
Power	External	DC 6.0 ~ 17V by DC adapter(PA01)	
Operating Temperature		−10°C to 60°C	
Storage Temperature		–20°C to 70°C	
Power consumption		3.5W(4hours with 2200mAH battery)	



| Optional Products

O External power adapter

PA01



External power or Canon LP-E6 battery can be used.

OHDMI Cable

O'HDIVII Cable			
Model	Length	Plug form	
HCRF07CRB	70cm		
HASN12CRF	120cm		
HASN12CRB	120cm		

OMini ball head

Model	Weight	Material
Mini ball head MBH-P	40g	Reinforced plastic
Mini ball head MBH-M	80g	Metal

O Composite cable

Model	Length	Plug form	
FCB041	70cm		
FCB042	100cm		RCA x 3EA

OArticulating Arm

Model	Length	Material
CA20	20cm	Metal
CA30	30cm	Metal

Cineroid



We will strive to create the best products and provide superb service.

Customer Support Center

Seculine Co., LTD.

Tel +82.2.850.3021 / Fax +82.2.850.3027

Rm.510, Kolon Science Valley #2, Guro-dong, 811, Guro-gu, Seoul, 152-878, Korea

Homepage www.cineroid.com E-mail support@secu-line.com

EVF1.0 Printed in Korea